

AMALFI

Instructions

- Do not use solvent adhesives!
- PES non-woven 40g/m² between PU upholstery foam and AMALFI is recommended.

Cleaning

- Cleaning of the surface should be undertaken using a mixture of luke warm water and a neutral soapy lather.
- Moisten a microfiber cloth with luke warm soapy water and remove dirt and marks with circular movements.
- More stubborn marks should be treated with a soft brush.
- The brush should likewise be moistened with luke warm soap suds and the marks removed by using a circular movement.
- The surface area, which has been cleaned with soap, should then be wiped down using a damp microfiber cloth that has been soaked in clean, luke warm water.
- Dry off the surface area!
- NO solvents or abrasive, scouring agents should be used.

Cleaning prior to disinfection

- Clean using lukewarm water and a microfibre cloth.
- Remove more stubborn marks with a PH-neutral soap.
- Rinse the soap with clear water.
- NEVER use detergents, solvents (alcohol), strong soap, bleaching or scouring agents: these can affect the synthetic leather and reduce the lifespan!
- Blood stains have to be removed immediately with cold water.
- Remove massage oil immediately with PH-neutral soap.
- Do not use leather maintenance products containing oil or grease.
- After disinfection, rinse the surface with water.

Resistent against disinfectants

- Use only disinfectants suitable for plastic surfaces.
- The disinfectants should not be changed.
- The resistance against disinfectants which are manufactured outside of the EU has to be examined in each case.
- Many clothing textiles have insufficient color fastness. Stains caused by jeans or other textiles are excluded from any guarantee.
- These cleaning recommendations are not a guarantee and do not absolve the user from a responsibility of due care when dealing with the materials and cleaning agents.



Wildeman



van Leeuwen